

Epson ELPFP14 mounting component - for projector



28-05-2024

SKU	V12H003P14
Produktbeskrivelse:	Epson ELPFP14 komponenter til montering - for projektor
Produkttype:	Komponenter til montering - loftsmonterbar
Monteringskomponenter:	Støtterør
Justerbar højde:	91.8-116.8 cm
Anbefalet brug:	Projektor
Designet for:	Epson EB-720, 725, 735, 750, 755, 972, 982, 992, E01, E20, FH52, L1050, L1060, L1065, L1070, L1075, L200, L250, L255, L520, L530, L630, L635, L720, L730, L735, L770, W06, W49, W50, W51, W52, X06, X49, EH-LS11000, LS12000, LS800, TW5700, TW5705, TW5820, TW5825, TW7000, TW710, TW7100, TW740, TW750

Generelt

Justerbar højde: 91.8-116.8 cm

Oplysninger om kompatibilitet

AV-møbler

Type:	Komponenter til montering
Monteringskomponenter:	Støtterør
Anbefalet brug:	Projektor
Placering/montering:	Loftsmonterbar

Oplysninger om kompatibilitet

Epson EB-1420WI, EB-1430Wi, EB-1440Ui, EB-1450Ui, EB-1460Ui, EB-1751, EB-1761W, EB-1771W, EB-1776W, EB-1840W, EB-1860, EB-1880, EB-1930, EB-1935, EB-1940W, EB-1945W, EB-1950, EB-1955, EB-1960, EB-1965, EB-1970W, EB-1975W, EB-1980WU, EB-1985WU, EB-2040, EB-2042, EB-2055, EB-2140W, EB-2155W, EB-2165W, EB-2245U, EB-2247U, EB-2250U, EB-2255U, EB-2265U, EB-4550, EB-4650, EB-4750W, EB-4770W, EB-4850WU, EB-4950WU, EB-525W, EB-530, EB-530 S, EB-535W, EB-536WI, EB-570, EB-585W, EB-585Wi, EB-585WS, EB-595Wi, EB-670, EB-675W, EB-675Wi, EB-685W, EB-685Wi, EB-695Wi, EB-696Ui, EB-700U, EB-720, EB-725W, EB-725Wi, EB-735F, EB-735Fi, EB-750F, EB-755F, EB-93H, EB-972, EB-980W, EB-982W, EB-990U, EB-992F, EB-D6155W, EB-D6250, EB-E01, EB-E20, EB-FH52, EB-G5900, EB-G7000W, EB-G7000WNL, EB-G7200W, EB-G7200WNL, EB-G7400U, EB-G7400UNL, EB-G7500UNL, EB-G7800, EB-G7805, EB-G7900U, EB-G7905U, EB-G7905UNL, EB-L1050U, EB-L1060UNL, EB-L1065UNL, EB-L1070U, EB-L1070UNL, EB-L1075U, EB-L1075UNL, EB-L200F, EB-L200SW, EB-L200SX, EB-L200W, EB-L250F, EB-L255F, EB-L400U, EB-L510U, EB-L520U, EB-L530U, EB-L610U, EB-L615U, EB-L630SU, EB-L630U, EB-L635SU, EB-L720U, EB-L730U, EB-L735U, EB-L770U, EB-S02, EB-S02H, EB-S03, EB-S04, EB-S17, EB-S18, EB-S31, EB-S39, EB-S41, EB-U04, EB-U05, EB-U32, EB-U42, EB-W03, EB-W04, EB-W05, EB-W06, EB-W110, EB-W18, EB-W28, EB-W31, EB-W32, EB-W39, EB-W42, EB-W49, EB-W50, EB-W51, EB-W52, EB-X03, EB-X06, EB-X11, EB-X15, EB-X18, EB-X24, EB-X27, EB-X31, EB-X39, EB-X41, EB-X49, EH-LS11000W, EH-LS12000B, EH-LS800W, EH-TW5100, EH-TW5210, EH-TW530, EH-TW5300, EH-TW5350, EH-TW550, EH-TW5600, EH-TW5650, EH-TW570, EH-TW5700, EH-TW5705, EH-TW5820, EH-TW5825, EH-TW5910, EH-TW6100, EH-TW6100W, EH-TW650, EH-TW6600W, EH-TW6700, EH-TW6700W, EH-TW6800, EH-TW7000, EH-TW710, EH-TW7100, EH-TW7200, EH-TW7300, EH-TW740, EH-TW7400, EH-TW750, EH-TW8400, EH-TW9000W, EH-TW9100, EH-TW9200, EH-TW9200W, EH-TW9300, EH-TW9300W, EH-TW9400, EH-TW9400W

Designet
for:

