

Epson ELPMB23 mounting kit - for projector



På lager(17)

SKU	V12H003B23
Produktbeskrivelse:	Epson ELPMB23 monteringssæt - for projektor
Produkttype:	Monteringssæt - loftsmonterbar
Monteringskomponenter:	Til loftmontering
Anbefalet brug:	Projektor
Materiale:	Stål

Designet for:

Epson EB-1485, 2042, 2055, 2140, 2245, 2247, 685, 720, 725, 735, 750, 755, 972, 980, 982, 990, 992, E01, E20, FH52, L200, L250, L255, S39, S41, U05, U42, W05, W06, W39, W42, W49, W50, W51, W52, X06, X39, X41, X49, EH-TW530, TW5600, TW5650, TW5700, TW5705, TW5820, TW5825, TW650, TW710, TW740, TW750

Generelt

Materiale: Stål

AV-møbler

Type:	Monteringssæt
Monteringskomponenter:	Til loftmontering
Anbefalet brug:	Projektor
Placering/montering:	Loftsmonterbar

Oplysninger om kompatibilitet



Oplysninger om kompatibilitet

Designet
for:

Epson EB-1400Wi, EB-1410Wi [240V], EB-1420Wi, EB-1430Wi, EB-1440Ui, EB-1450Ui, EB-1460Ui, EB-1485Fi, EB-1720, EB-1725, EB-1735W, EB-1750, EB-1751, EB-1760W, EB-1761W, EB-1770W, EB-1771W, EB-1775W, EB-1776W, EB-1780W, EB-1785W, EB-1795F, EB-1840W, EB-1860, EB-1880, EB-1900, EB-1920W, EB-1925W, EB-1930, EB-1935, EB-1940W, EB-1945W, EB-1950, EB-1955, EB-1960, EB-1965, EB-1970W, EB-1975W, EB-1980WU, EB-1985WU, EB-2040, EB-2042, EB-2055, EB-2140W, EB-2155W, EB-2165W, EB-2245U, EB-2247U, EB-2250U, EB-2255U, EB-2265U, EB-470, EB-475W, EB-475Wi, EB-485W, EB-485Wi, EB-525W, EB-530, EB-530S, EB-535W, EB-536Wi, EB-570, EB-585W, EB-585Wi, EB-585WS, EB-595Wi, EB-670, EB-675W, EB-675Wi, EB-685W, EB-685Wi, EB-695Wi, EB-696Ui, EB-720, EB-725W, EB-725Wi, EB-735F, EB-735Fi, EB-750F, EB-755F, EB-824H, EB-825H, EB-826WH, EB-93H, EB-945H, EB-955WH, EB-965H, EB-972, EB-980W, EB-982W, EB-98H, EB-990U, EB-992F, EB-D6155W, EB-D6250, EB-E01, EB-E20, EB-FH52, EB-L200F, EB-L200SW, EB-L200SX, EB-L200W, EB-L250F, EB-L255F, EB-S02, EB-S02H, EB-S03, EB-S04, EB-S10, EB-S17, EB-S18, EB-S27, EB-S31, EB-S39, EB-S41, EB-S82, EB-S92, EB-U04, EB-U05, EB-U32, EB-U42, EB-W03, EB-W04, EB-W05, EB-W06, EB-W110, EB-W18, EB-W28, EB-W29, EB-W31, EB-W32, EB-W39, EB-W42, EB-W49, EB-W50, EB-W51, EB-W52, EB-W8, EB-X03, EB-X06, EB-X10, EB-X11, EB-X15, EB-X18, EB-X24, EB-X27, EB-X31, EB-X39, EB-X41, EB-X49, EB-x92, EH-TW450, EH-TW480, EH-TW490, EH-TW5100, EH-TW5200, EH-TW5210, EH-TW530, EH-TW5300, EH-TW5350, EH-TW550, EH-TW5600, EH-TW5650, EH-TW570, EH-TW5700, EH-TW5705, EH-TW5820, EH-TW5825, EH-TW650, EH-TW710, EH-TW740, EH-TW750, EMP-1700, EMP-1710, EMP-1715, EMP-1810, EMP-1810p, EMP-1815, EMP-1815p, EMP-400W, EMP-400We, EMP-62, EMP-750, EMP-760, EMP-765, EMP-82, EMP-822, EMP-822H, EMP-82e, EMP-83, EMP-83e, EMP-83H, EMP-83He, EMP-S3, EMP-S4, EMP-S5, EMP-X3, EMP-X5 | Epson Megaplex MG-850HD | Epson PowerLite 1710C, 1715C, 400W