

Epson - photo paper - glossy - 20 sheet(s) - A4 - 200 g/m²



På lager(58)

SKU	C13S042538
Produktbeskrivelse:	Epson - fotopapir - skinnende - 20 ark - A4 - 200 g/m²
Produkttype:	Fotopapir
Overfladefinish:	Skinnende
Mediестørrelse:	A4 (210 x 297 mm)
Medievægt:	200 g/m²
Antal inkluderet:	20 ark
Kompatibel med:	EcoTank ET-1110, 2750, 2751, 2756, 2850, 2851, 2856, 4750, 4850; EcoTank Photo ET-8500; EcoTank Pro ET-5800; Expression ET-2710; Expression Home HD XP-15000; SureColor P706, SC-T5160, T3160, T5160; WorkForce ET-4700, WF-2810, 7725, 7840, 7845; WorkForce Pro WF-3725, 4745, 4835, C5790

Medie

Medietype:	Fotopapir
Overfladefinish:	Skinnende
Mediестørrelser:	A4 (210 x 297 mm)
Antal inkluderet:	20 ark
Medievægt:	200 g/m²

Oplysninger om kompatibilitet

Oplysninger om kompatibilitet

Kompatibel
med:

Epson L385, L555, L565 | Epson Artisan 1430, 635 | Epson EcoTank ET-1110, ET-2750, ET-2750U, ET-2751, ET-2756, ET-2850, ET-2850U, ET-2851, ET-2856, ET-3750, ET-4750, ET-4750 Unlimited, ET-4750U, ET-4850, ET-4850U, ET-7700, ET-7750 | Epson EcoTank Photo ET-8500 | Epson EcoTank Pro ET-5800 | Epson Expression ET-2710 | Epson Expression Home XP-100, XP-200, XP-200 Small-in-One, XP-202, XP-205, XP-212, XP-215, XP-220, XP-225, XP-235, XP-235A, XP-240, XP-245, XP-247, XP-300, XP-300 Small-in-One, XP-310, XP-314, XP-320, XP-324, XP-33, XP-342, XP-345, XP-400, XP-400 Small-in-One, XP-405, XP-410, XP-415, XP-420, XP-422, XP-424, XP-432, XP-435, XP-442, XP-445, XP-530 | Epson Expression Home HD XP-15000 | Epson Expression Photo HD XP-15000, XP-55, XP-850, XP-860, XP-950 | Epson Expression Premium XP-510, XP-530, XP-540, XP-540 Media Bundle, XP-600, XP-6000, XP-6005, XP-610, XP-615, XP-620, XP-630, XP-635, XP-640, XP-645, XP-700, XP-710, XP-800, XP-810, XP-900, XP-900 Stickers | Epson Stylus NX130, NX230 Small-in-One, NX635 | Epson SureColor P706, SC-P405, SC-T5160, T3160, T3160M, T5160M | Epson WorkForce 435, 545, 7010, ET-4500 EcoTank, ET-4700, WF-100, WF-100W, WF-2010W, WF-2510WF, WF-2520, WF-2520NF, WF-2530, WF-2530WF, WF-2540, WF-2540WF, WF-2630, WF-2630WF, WF-2650DWF, WF-2660, WF-2660DWF, WF-2750DWF, WF-2760DWF, WF-2810, WF-3520, WF-3520DWF, WF-3530, WF-3530DTWF, WF-3540, WF-3540DTWF, WF-3620, WF-3620DWF, WF-3620DWF Stickers, WF-3640, WF-3640DTWF, WF-7110DTW, WF-7510, WF-7520, WF-7610, WF-7610DWF, WF-7620, WF-7620DTWF, WF-7720, WF-7725, WF-7840, WF-7845 | Epson WorkForce Pro WF-3725, WF-4630, WF-4630DWF, WF-4640, WF-4640DTWF, WF-4745, WF-4835, WF-5190, WF-5190DW, WF-5690, WF-5690DWF, WF-6090DW, WF-6590DWF, WF-C5790DWF, WF-C5790DWF BAM, WF-C5790DWF Power PDF, WF-R5190 DTW Flex, WF-R5190 DTW Flex BAM, WF-R5690 DTWF Flex BAM, WF-R5690DTWF Flex, WF-R8590 D3TWFC Flex, WF-R8590 DTWFC

Oplysninger om kompatibilitet

