

# Xerox printer snap-in holder



Ikke på lager

SKU 497N02966

Produktbeskrivelse: Xerox klik ind-holder til printer

Produkttype: Klik ind-holder til printer

Farve: Hvid

Designet for:

Xerox 6655, B225, B230, B235, B305, B310, B315, C230, C235, C315; Color C60, C70; ColorQube 9300, 9303; Phaser 3330, 6510; VersaLink B400, B600, B610, C400; WorkCentre 3655, 4265, 5325, 5330, 5335, 5945, 5945/5955, 5955, 6515, 6655, 7220, 7903, 7970

## Generelt

Produkttype: Klik ind-holder til printer

Forsendelsesdimensioner (VxDxH)/vægt: 0.3 kg

Farve: Hvid

## Diverse

Egenskaber: Klæbende bund

## Oplysninger om kompatibilitet

Xerox 6655V\_XM, B225, B225/DNI, B225V\_DNIUK, B230, B230/DNI, B230V\_DNIUK, B235, B235V\_DNIUK, B305V\_DNIUK, B310, B310/DNI, B310V\_DNIUK, B315V\_DNIUK, C230, C230/DNI, C230V\_DNIUK, C235, C235/DNI, C235V\_DNIUK, C315V\_DNIUK ; Xerox Color C60PROV/U, C60PROV/Y, C70PROV/U, C70PROV/Y ; Xerox ColorQube 9300V\_F, 9303V\_AF ; Xerox Phaser 3330V\_DNM, 6510V/DNIS, 6510V/DNS, 6510V/NS ; Xerox VersaLink B400/DNM, B400/YDN, B400DN, B400N, B400V/DN, B400V/DNM, B400V\_N, B600/DN, B600/DNM, B600/DT, B600/DX, B600/DXF, B600/DXP, B600V\_DN, B600V\_DNM, B610/DN, B610/DNM, B610/DT, B610/DX, B610/DXF, B610/DXP, B610V\_DN, B610V\_DNM, C400/DNM, C400DN, C400N, C400V/DN, C400V/DNM ; Xerox WorkCentre 3655/S, 3655/SM, 3655/X, 3655/XM, 3655/YXM, 3655IV\_S, 3655V\_S, 3655V\_SM, 3655V\_X, 3655V\_XM, 4265/S, 4265/SM, 4265/X, 4265/XF, 4265/XFM, 4265/XM, 4265/YSM, 4265V\_S, 4265V\_SM, 5325/C, 5325/CH, 5325/PH, 5325/PHXF, 5330/C, 5330/P, 5330/PH, 5330/PHXF, 5335/C, 5335/P, 5335/PH, 5945, 5945/5955 base, 5945V\_F, 5945V\_K, 5955, 5955V\_F, 5955V\_K, 6515V/DNIS, 6515V/DNS, 6515V/NS, 6655, 6655/X, 6655/XM, 6655/YXM, 6655i, 6655I/YXM, 6655IV\_X, 6655V\_X, 7220/PXF2I, 7903V\_F, 7970, 7970V\_F

Designet for: